

Date

* YM86E3G 100Specification

Approved by

Specific	Notes	
Standard Model	YM86E3G-100	Basic Model
Extended Model		

Revision Record			
Version	Reviser	Description	Date
	Checked by		Date



1 Specification

1.1 Basic Specification

1.1 Basic opcomoation		
Model	YM86E3G-100(Including Extended Model)	
Туре	Low Side Shell Design Scroll Compressor	
Application	Air conditioning	
Refrigerant	R404A	
Displacement(cc/rev)	83.3	
Cooling Capacity(W) ^(a)	10200	
Input Power(W) ^(a)	5514	
RLA(A) ^(a)	26.4	
Cooling COP(W/W) ^(a)	1.85	
Power Supply	208-230V/1~/60Hz	
Min. Operating Voltage(V)	187	
Max. Operating Voltage(V)	253	
LRA(A)	140	
Max. Operating Current(A) ^(b)	40.1	
Rated Speed(r/min) ^(a)	3500	
Compressor Weight(With Oil)(kg)	38	
Oil Type	POE	
Oil Kinematic Viscosity(cSt, 40°C)	32	
Oil Density(kg/L, 20℃)	0.977	
Primary Charge(L)	1.6	
Recharge(L)	1.45	
Oil Circulation Rate ^(a)	≤1%	
Rated Sound(Sound Power)(dBA) ^(c)	75	
Max. Operating Sound in Running Envelope (Sound Power)(dBA)	80	
Vibration Displacement Peak-Peak(mm) ^(d)	≤0.1	
Moisture(mg)	≤500	
Impurity(mg)	≤100	
LVS(V) ^(e)	177	
MOV (V) ^(f)	187	
Start Capacitor(µF/V)	250	
Start Relay	HLR3800-3F3C	
Run Capacitor(µF/V)	100/450	
IP Class of Terminal Box	IP21	
Compressor Color	Black	

1.2 Motor Parameters

Motor Type	Single-phase asynchronous motor
Motor Pole	2
Motor Insulation Class($^{\circ}\!\mathbb{C}$)	130(B Class)
Line to Line Resistance UV(CS)(Ω, 25℃)	0.777(±10%)
Line to Line Resistance UW(CR)(Ω, 25°C)	0.395(±10%)
Line to Line Resistance VW(SR)(Ω, 25°C)	1.172(±10%)
Dielectric Strength	2000VAC / 1s / 50Hz, Leakage Current≤5mA
Insulation Resistance(MΩ)	≥20
Ground Resistance(Ω)	≤0.1

1.3 Safety Operating Limit

Tightness Test Pressure(MPa)	3.8-4.0		
Max. Operating Pressure			
High Side(MPa)	H2 2/L2 0		
Low Side(MPa)	H3.2/L2.0		
Compressor FreeSpace(Without Oil)			
High Side(L)	H1.0/L3.7		
Low Side(L)	П1.0/L3.7		
Max. Refrigerant Charge(kg)	See Notes		
	≤125		
Discharge Temperature Limit(℃)	(120mm to compressor discharge connection		
	and well insulated)		
Start-Stop Interval	See Notes		

Performance Condition:

Condition	Condition Description
а	Rated Condition
b	Max. Load Condition, 90% Rated Voltage
С	Rated Condition, A Weighted Sound Power
d	Rated Condition, Max Operating Normal Displacement of
	Compressor Housing
е	Discharge Pressure and Suction Pressure: Saturated Refrigerant
	Pressure at 40°C
f	Max. Load Condition

2 Rated Condition, 48 Hours Break-in-Running before implementing Performance and Sound Testing

Item	Rated Condition	Max. Load Condition	
E.T.(°ℂ)/C.T.(°ℂ)/S.H.(K)/	-6.7/48.9/11.1/0/35	10/65/11.9/0/46.1	
S.C.(K)/A.T.(°ℂ)	6.17 16.67 11.176766	10/00/11.0/0/40.1	
Cooling Capacity Deviation	≥92.5%	-	
Power Deviation	≤107.5%	-	
COP Deviation	≥92.5%	-	

3 Internal Protector


Protection Method	Config	Parameter		
		Vendor	Vendor1	Vendor2
		Model	UP16QC051A-XX	
Internal Overload With		Open Temp.(℃)	150±5	
Protector	VVIIII	Close Temp. (°C)	80±9	
		Short Time Trip	155A	Α
		Short Time Trip	3-10s	S
Internal Pressure	With	-MPa		
Relieve Valve	vviui			

4 Accessory

YM86E3G-100				
Item	Name	P.N.	PCS	
1	Grommet	070-0003-00	4	
2	Sleeve	010-0014-00	4	
3	StartBox	110-0076-10	1	
4				
5				



- 5 Compressor Operating Envelope
- 5.1 Compressor Operating Envelope



- 5.2 EVI control logic(only for EVI module)
 - Recommend system subcooling 5K
 - DLT≤95°C,control superheat of injection line=5K
 - DLT>95°C,control DLT=95°C
 - Max injection pressure≤2.0MPa
- 6 Compressor Performance Sheet
 - Performance Based on Superheat is within the Operating Envelope, Subcooling after Condenser is 0K;
 - Performance Calculated by Coefficients of Polynomial is Only Suitable for the Condition within Operating Envelope
 - Capacity, Power can be Calculated by Coefficients of Polynomial

6.1 Performance Table

Item	E.T.(°C)	-20	-10	0	10
item	C.T.(°C)				
Heating	50				
Cap.(W)	40				
(Cooling Cap.	30				
O a alian a O a a	50	6665	9706	13760	19189
Cooling Cap. (W)	40	7787	11385	16251	22749
((V)	30	8782	12936	18614	26181
	50	4859	5309	5715	6061
Power(W)	40	4106	4490	4853	5180
	30	3485	3817	4153	4477

6.2 Ten Coefficients of Polynomial

Expression	$z = p0 + p1*x + p2*y + p3*x^2 + p4*x*y + p5*y^2 + p6*x^3 + p7*x^2*y + p8*x*y^2 + p9*y^3$				
Description	z:Cooling Capacity(W) or Power (W) Specially: Heating Capacity(W)=Cooling Capacity(W)+Power (W) x: E.T. °C y: C.T. °C p0~p9: Coefficients of Polynomial				
Cooling Cap.	Value	Value Power Value			
Factor		Factor			
р0	26440.6224	p0	2851.164		
p1	938.001 p1 38.436		38.436		
p2	-309.409224 p2 27.132				
р3	13.288704 p3 0.301351				
p4	-9.38676 p4 -0.413402				
р5	2.369244 p5 0.451067		0.451067		
р6	0.060696 p6 -0.002554		-0.002554		
p7	-0.128148 p7 -0.012011		-0.012011		
р8	-0.000234	p8	0.00804		
р9	-0.025068 p9 0.003039				

Notes: Coefficients of polynomial are based on the fitting results of some sample data, which can be used as a reference of compressor selection, but cannot completely eliminate customer's test.




7 Notes


- 7.1 It is not allowed to perform vacuum in the system by using the refrigeration compressor. The compressor can start only after the refrigerant charged. In some cases, such as on the field site, if it is limited by the situation that can't charge the required volume of refrigerant, 50% of the required refrigerant is charged necessary before the compressor starts. Double check the system and make sure everything is under safe status, then power on the compressor and charge the remained refrigerant when the compressor is running.
- 7.2 It is not allowed to charge the refrigerant from the suction or discharge line closes to the compressor. The charge port should be arranged on the connection pipe of suction line accumulator or receiver, which is on the side far away to the compressor, to avoid the liquid refrigerant flood back.
- 7.3 Refrigerant charge limitation: the ratio between the weight of oil and refrigerant should be >=0.4.
- 7.4 It is not allowed to vacuum by compressor, not allowed to run the compressor without refrigerant, and not allowed to run the compressor on the reversed direction for long duration.
- 7.5 The compressor can only work with approved refrigerant.
- 7.6 The compressor is not allowed to work outside its envelope, the system should guarantee the suction line superheat and avoid the liquid refrigerant flood back.
- 7.7 When the suction and discharge plugs are removed, the assembly and brazing should be done in 15 minutes.
- 7.8 The frequently start/stop should be avoided. The suggested minimum continuous running time is 10 minutes to guarantee the safe oil level (>=50% initial charge volume), the suggested minimum interval duration between start and stop is 3 minutes.
- 7.9 The deviation of supplied voltage should be less than +/-10% of rated voltage.
- 7.10 A 70W crankcase heater is recommended to avoid the refrigerant migration during the off circle and flood start. The crankcase heater should be power on 12 hours earlier than the first start or restart after long duration off.
- 7.11 The system should be equipped with necessary protection devices, such as pressure, temperature, oil return, overcurrent and phase fault, etc.
- 7.12 The compressor is not allowed to lay down or place upside down during transportation, stock and installation. The maximum inclination is 15° when the compressor is running.

8 Drawings


8.1 Outline Drawing



8.2 Sleeve Drawing




8.3 Grommet Drawing





9 Single Phase Compressor Wiring Diagram





10 Application

See Details in the $\,\,$ $\,$ $\,$ $\,$ YM serial MBP refrigerant scroll compressor application manual $\,$